



Безымянный - TwinCAT System Manager

File Edit Actions View Options Help

SYSTEM - Configuration  
 PLC - Configuration  
 I/O - Configuration  
 I/O Devices  
 Device 1 (EtherCAT)  
 Device 1-Image  
 Device 1-Image-Info  
 Inputs  
 Outputs  
 InfoData  
 Term 1 (EK1100)  
 InfoData  
 Term 2 (EL1502)  
 CNT TxPDO-Map  
 WcState  
 InfoData  
 Term 3 (EL9011)  
 Mappings

General EtherCAT DC **Process Data** Startup CoE - Online Online

Sync Manager:

SM	Size	Type	Flags
0	128	MbxOut	
1	128	MbxIn	
2	0	Outputs	
3	6	Inputs	

PDO List:

Index	Size	Name	Flags
0x1A00	6.0	CNT TxPDO-Map Ch.1	F
0x1A01	6.0	CNT TxPDO-Map Ch.2	F
0x1A02	6.0	CNT TxPDO-Map	F
0x1600	6.0	CNT RxPDO-Map Ch.1	F
0x1601	6.0	CNT RxPDO-Map Ch.2	F
0x1602	6.0	CNT RxPDO-Map	F

PDO Assignment (0x1C12):

0x1600  
 0x1601  
 0x1602

СНЯТЬ МЕТКУ С 0x1602!

Download  
 PDO Assignment  
 PDO Configuration

PDO Content (0x1A00):

Index	Size	Ofs	Name	T
0x6000:01	0.1	0.0	Output functions enabled	B(
0x6000:02	0.1	0.1	Status of output	B(
0x6000:03	0.1	0.2	Set counter done	B(
0x6000:04	0.1	0.3	Counter inhibited	B(
...	0.1	0.4	...	
0x6000:06	0.1	0.5	Status of input clock	B(

Load PDO info from device  
 Sync Unit Assignment...

Безымянный - TwinCAT System Manager

File Edit Actions View Options Help

SYSTEM - Configuration  
 PLC - Configuration  
 I/O - Configuration  
 I/O Devices  
 Device 1 (EtherCAT)  
 Device 1-Image  
 Device 1-Image-Info  
 Inputs  
 Outputs  
 InfoData  
 Term 1 (EK1100)  
 InfoData  
 Term 2 (EL1502)  
 CNT TxPDO-Map  
 CNT RxPDO-Map Ch.1  
 CNT RxPDO-Map Ch.2  
 WcState  
 InfoData  
 Term 3 (EL9011)  
 Mappings

General EtherCAT DC **Process Data** Startup CoE - Online Online

Sync Manager:

SM	Size	Type	Flags
0	128	MbxOut	
1	128	MbxIn	
2	12	Outputs	
3	6	Inputs	

PDO List:

Index	Size	Name	Flags
0x1A00	6.0	CNT TxPDO-Map Ch.1	F
0x1A01	6.0	CNT TxPDO-Map Ch.2	F
0x1A02	6.0	CNT TxPDO-Map	F
0x1600	6.0	CNT RxPDO-Map Ch.1	F
0x1601	6.0	CNT RxPDO-Map Ch.2	F
0x1602	6.0	CNT RxPDO-Map	F

PDO Assignment (0x1C12):

0x1600  
 0x1601  
 0x1602 [excluded by 0x1601]

Поставить метки для 0x1600 и 0x1601

Download  
 PDO Assignment  
 PDO Configuration

PDO Content (0x1A00):

Index	Size	Ofs	Name	T
0x6000:01	0.1	0.0	Output functions enabled	B(
0x6000:02	0.1	0.1	Status of output	B(
0x6000:03	0.1	0.2	Set counter done	B(
0x6000:04	0.1	0.3	Counter inhibited	B(
...	0.1	0.4	...	
0x6000:06	0.1	0.5	Status of input clock	B(

Load PDO info from device  
 Sync Unit Assignment...