

LOGIN KS2000

IP

The screenshot displays the Beckhoff KS2000 configuration software interface. The main window is titled "Beckhoff KS2000" and has a menu bar with "Project", "Online", "Options", and "Help". A toolbar is located below the menu bar. On the left side, there is a tree view showing the project structure for "Pos 0: BK9000-0000 ()". The "Fieldbus: Settings" folder is selected, and a list of tables is shown, including "000: Configuration Coupler", "002: Table 2", and various "Config local inputimage" and "Config local outputimage" entries.

The main configuration area is titled "Type: BK9000-0000 ()". It contains the following settings:

- AMS-NetID: 192.168.17.0.1
- MAC-ID: 00-01-05-00-57-05
- Boot-P active
- Obtain an IP address from a DHCP server (DIP 10)

There are two sections for IP address configuration:

- DHCP IP address:** DHCP Name is "BK9000". IP Address, SubNet Mask, DNS Server, and Gateway are all set to 0.0.0.0.
- Specific IP address:** IP Address is 192.168.17.0, SubNet Mask is 255.255.0.0, and Gateway is 0.0.0.0.

Additional options are checked:

- 100 Mbps = checked / 10 Mbps = unchecked
- Full duplex = checked / Half duplex = unchecked
- ANEG enabled

Buttons for "Apply" and "Cancel" are located on the right side of the configuration area.

At the bottom of the window, there is a status bar showing "Online", "Check diagnostic data... OK", "Resume without error", and the date "28.07.2004" at "10:14". The Windows taskbar at the very bottom shows the "Пуск" button and several open applications, including "Beckhoff KS2000".

Twincat system manager
 I/O Devices – Append device...
 Virtual Ethernet Interface.
 Scan Boxes... - Twincat

PC Ethernet.

